

STEALTH

READY • FIT • GO

P3 (R) SAFETY RESPIRATOR

F01.1001 Stealth Half Face Respirator, Size S/M, include 2pcs of HEPAC P3 (R) filters



- Low-profile design maximizes field of vision. Fits easily under most welding helmets and safety visors.
- Ergonomic design, extremely low breathing resistance makes the stealth mask suitable for most work activities ranging from low to strenuous, and short to extended periods.
- Manufactured from high grade materials which are odour free, non-allergenic (The TPE mask body material is latex and silicone free).
- Single piece head and neck strap runs with ease through four anchor points optimally positioned on the grill whilst the strap is easily tensioned by simply pulling the strap ends through the self-locking neck clips providing a customized user face fit.
- Exclusive HEPACTM (High Efficiency Particulate Air Composite) media pleated filter design provides additional surface area for maximum efficiency and filter life, providing optimal efficiency in both humid and non-humid environments. The StealthTM HEPACTM P3(R) filters provide 99.95+% filtration of airborne particles and oil aerosols at 0.3 microns and above.
- Protective grill, with sleek downward facing louvres protecting the filter from debris and dust in harsher environments and is easily removed for filter replacement.
- Large non-return exhaust valve eases breathing and reduces user fatigue, positioned to exhale downwards avoiding condensation of visors and eye protection.
- Sample port. The only known respirator on the market with integral sample port & plug to allow non-destructive quantitative face fit testing of each unit, thus the fit of each specific respirator to the end user can be tested without the need for additional fittings or disposing of the tested unit.