
CLEANROOM ANTISTATIC DRY MOP

Technical Data Sheet

Mop Head Cover	: Laundered-100% knitted Polyester with ESD Microfiber
Mop Head Design	: Flat with gray foam pad
Mop Head Assembly	: Low-profile swivel head
Mop Head Sizes	: 40cm x 22cm
Handle Material	: Alloy Aluminium
Handle Length	: Minimum = 69cm (27inches) Maximum = 122cm (48inches)
Replacement Parts	: ESD Polyester Mop Cover
Surface Resistivity	: $10^7 - 10^9$ ohm (Mop Cover)
Recommendation	: Suitable for Cleanroom Class 1,000 (ISO 6) and above.
Mop Set Comes with	: Alloy Aluminium Handle X1pc : Mop Head (Foam Pad) X1pc : ESD Polyester Mop Cover X1pc



Usage instruction:

Firstly, use the ESD Mop without using water. Treat the ESD Mop as a broom to sweep dust away. Then remove the ESD Polyester Mop Cover for rinsing to remove all dust that is still sticking onto the cover. With the dampened Mop Cover, use it along with very mild floor cleaning detergent to mop the floor area. Upon completion, rinse the mop cover thoroughly but gently and put to dry.



NOTE: The information and pictures contain herein is believed to be reliable but no representations, guarantees or warranties of any kind are made as to its accuracy or suitability for particular applications
